



DISH COVER

For Microwave oven

WHY USE THE DISH COVER?

The WPRO Plastic Dish Cover for MWO prevents spillage while cooking or heating food in your microwave. Using regularly the lid, the oven cavity will remain clean for your best and safe cooking. Diam. 27 cm., to fit the majority of MWO models. Universal.

COOKING - MWO



INSTRUCTIONS FOR USE

Place the lid on the plate or on the container that you are placing in the microwave to heat or cook the food. Dishwasher safe.

 THE WPRO +

Tested and recommended by



Food grade for your safety





480181700016	PLL270	8015250038637
--------------	--------	---------------